Title: Installation of the LeMond Revmaster Bottom

Bracket Spindle Shaft

Date: February 13, 2012 Ver. 4

When installing your new bottom bracket spindle shaft, it is important that you note which way it is to be used by looking at the spindle closely. A quick measurement will determine the proper orientation of the spindle.

The spindle has different lengths from the edge of the raised portion to the ends. The measurement of roughly 1 3/4" will be on the RIGHT side and will attach to the RIGHT crank. The opposite side measures roughly 11/2" from the end to the edge of the raised portion, it will attach to the LEFT crank arm.

