


LeMond RevMaster Exploded Views

15100-6


Document NO: 300138

Rev. 5


2-16-09




Front Stabilizer/Belt Cover Exploded View




Left Side/Rear Stabilizer







15680 Handlebar Assembly

(Bottle Holder Assembly 15575 not included)




Seat Post Assembly






15387 Flywheel,
Nickel Plated


14083 Flat Head
Screw, M6x16(x3)



Flywheel Assembly



15341 Brake Assembly



15526 Fender Assembly

(Shoulder Bolts 15193 & 15194 Not Included)

REVMaster "PRO"- PARTS LIST

Item Number	Item Description	
15682	ACCESSORY KIT	
15401	ASSY INSTRUCTIONS	
15668	ASSY, BOTTOM BRACKET	
15443	ASSY, BRAKE ROD	
15526	ASSY, FENDER	
15646	ASSY, POST HANDLEBAR	
15534	ASSY, PLUNGER POST	
15648	ASSY, PULLEY, RT CRANK	
15575	ASSY, WATER BOTTLE HOLDER	
15238	BEARING, BRAKE CONTACT	
15603	BEARING, HANDLEBAR POST	
15653	BEARING, IDLER	
15353	BEARING, PLUNGER POST	
15604	BEARING, SEAT POST	
15528	BEARING, SPRING (FENDER)	
15168	BEARING, SLIDER (HANDLE BAR)	
15296	BELT, DRIVE	
14044	BOLT, CRANK PULLEY	
15193	BOLT, SHOULDER (FENDER) FEM	
15194	BOLT, SHOULDER (FENDER) MALE	
15341	BRAKE ASSY	
15509	BUMPSTOP, HANDLEBAR POST	
15350-1	CADENCE PILOT METER	
15332	CAP, CASTING (BLK)	
15331	CAP, CASTING (YLV)	
15120	CAP, END (STABILIZER)	
15265	CAP, END TRACK	
15402	CD, REV2	
15609	CLAMP, SEAT	
15135	COVER, BELT (INSIDE)	
15319	COVER, BELT LM	
15527	COVER, BRAKE (FENDER)	
15134	COVER, BRAKE	
15136	COVER, MAGNET ACCESS	
15115	COVER, STRETCH PAD	
15363	COVER, X (GASKET FRONT)	
15362	COVER, X (GASKET REAR)	
15359	COVER, X (GASKET TOP)	
15476	COVER, X LEFT	
15477	COVER, X RIGHT	
15377	CRANK, LEFT	
15596	DECAL, CROSS FRAME REV2 BLK	
15387	FLYWHEEL	
15358	FUSE, POST PLUNGER	
15551	HANDLE, ADJ (BLK)	
15571	HANDLE, ADJ (YLV)	
15357	HANDLE, DIP (HBR) BLK	
15345	HANDLE, DIPPED (YELLOW)	
15471	HANDLE, POST (LIMITER)	
15680	HANDLEBAR ASSY BLK	
15615	HANDLEBAR ASSY YLV	
15448	HUB ASSY, FLYWHEEL	
15647	INDICATOR, HANDLEBAR POST	
15490	LABEL, ELLIPSE	

15320	LABEL, LF	
14048	LEVELER, LEG	
15370	MAGNET HOLDER	
15403	MANUAL, OWNERS	
15507	MOUNT, WATER BTL CAGE (FRONT)	
15506	MOUNT, WATER BTL CAGE (BACK)	
15342	NUT, FRAME (BRAKE)	
15155	NUT, PILLOWBLCK W/FLANGE	
15422	NUT, PILLOWBLOCK	
14055	NUT, ROD (BRAKE)	
N40606081	NUT, WASHER (FRT STAB)	
15602	BRAKE, PAD LEATHER W/FOAM	
15449	PAINT, TOUCH UP BLK	
250201	PAINT, TOUCH UP YLW	
14139	PEDALS, DUAL-SIDED (PAIR, W/SPD CLIP)	
VP-518-AT	PEDALS, STANDARD (PAIR)	
11248	PEDAL, STRAPS (EACH)	
15382	PILLOWBLOCK, LEFT (YLW)	
15444	PILLOWBLOCK, LEFT BLK	
15354	PIN, HANDLE BAR POST	
15169	PLUG, SLIDER (HANDLE BAR)	
15492	PLUNGER, HBAR SLIDER	
15673	POST PLUG ASSY	
15374	POST, IDLER TRAV	
15670	POST, SEAT (WELDMT)	
SL10501081	SCREW, COUNTERSUNK (PAD PRT X L)	
SL10400881	SCREW, COUNTERSUNK	
SL10602091	SCREW, FLAT CRANK ARM TO PULLEY	
SC10401081	SCREW, DOME (CASTING CAP)	
SC40604081	SCREW, DOME (FRT STAB)	
SC10400581	SCREW, DOME	
SC10501081	SCREW, DOME	
SC10604081	SCREW, DOME	
SC10802084	SCREW, DOME CROSS ARM BOLTS	
SC20401581	SCREW, DOME	
14083	SCREW, FLAT	
SA20401381	SCREW, SOCKET (PAD PRT COVER X R)	
SA10400681	SCREW, SOCKET (TRK END CAP)	
SA10601581	SCREW, SOCKET	
SA10606011	SCREW, SOCKET	
SA2401381	SCREW, SOCKET	
SA40603581	SCREW, SOCKET	
15616	SEAT W/CLAMP	
15333	SLEEVE RETAINER, ED	
15664	SLIDER, SEAT	
15373	SPACER, BRAKE (UPPER)	
14020	SPACER, IDLER	
15260	SPRING, BRAKE (LWR)	
15226	SPRING, BRAKE (UPPER)	
15424	SPRING, FENDER	
15630	STABILIZER, FRONT	
15631	STABILIZER, REAR	
HROMNTRX	STRAP, HEART RATE	
250204B-BLK	TOOL KIT- BLK	
250204B-YLW	TOOL KIT- YLW	
15372	TUBE, DISTANCE BRAKE	
14049	WASHER, BRASS	
W10501081	WASHER, FLAT	
15131	WASHER, IDLER (OVAL)	
W30500681	WASHER, SPRING	

W30800881	WASHER, STAR	
15269	WELDMENT, FENDER (ED)	
15126	WHEELS, TRANSPORT	

5/28/08