

G3S55 Rotary Torso Parts List.xls

Ref #	SAP #'s	Description	Q'ty	Unit of Measure
AB1	069525	Painting;Frame Set;GY;GM24	1	EA
AC1	077987	Base welding Set;painting;GM24	1	EA
AD1	054317-B	Painting;SwivelArmSet;;;;;GM24;GM24-AD1	1	SET
AF1	054320-B	Painting;Belt AdjustableMast Set;;;;;GM	2	SET
AF2	054358-B	Painting;BeltFixSet;;;;;GM24;GM24-AF2;	1	EA
AF3	078193	Cam Set;Painting;;GM24	1	EA
AF4	014780-H	Pulley;;;;;;GM01	8	SET
AK1	013418-Z	Top Weight Plate Set	1	EA
AL1	015771-A	Painting;Hook;;;;;GM01	2	SET
AL2	015772-A	Painting;Incremental ADJ Rod;;;;;GM01	2	SET
B03	008443-C	Supt Plate;Pulley;U;SPC;;;;;GM01;GM01-B04	2	PCS
B09	008504-A	89BALANCE FIXING PLATE	2	PCS
B11	008447-A	UPPER PULLEY FIXING PLATE	2	PCS
B16	031370-A	Supt Plate;Pulley;;SPC;4.0t;;GM19;GM19-	2	PCS
B21	000509-E	Foot pad;;;;;?89;;GM01	4	PCS
B22	004975-00	Insert Nut;ALS7-8125-3.8(0.5-3.8);	22	PCS
B23	020410-A	Insert Nut;;NLS7-580-5.7;;;;;	4	EA
B25	000508-D	Foot Pad;?60;GM01	2	PCS
B26	092139	Water Bottle Holder Set	1	Set
B26	087655	Bottle Holder Only	1	EA
B26	087656	Towel Rack Only	1	EA
B26	087659	Towel Rack Snug Plate Only (Small square piece)	1	EA
B27	004703-AF	Screw;Hex Socket;Flat;M8x1.25Px20L;Adher	6	EA
B28	004535-AB	Screw;Hex Socket;Round;M8x1.25Px30L;Adhe	4	EA
B30	005084-00	WASHER FT M5.3X10X1 CHM	8	PCS
B31	004601-AB	Screw;Hex;M5x0.8Px15L;15L;Zn Plate;	8	PCS
B42	008589-F	Fixing Horn Plate;Cover;D;SPC;;Zn Plate(2	EA
B43	067544-A	Screw;Phillip;BH;M4x0.7Px12L;Adhere;	10	EA
B44	008450-G	UPPER COVER OUTER L-SHAPE BRACKET;SPHC:1	2	EA
B45	022204-A	REAR UPPER COVERSNUG PIECE	2	EA
B46	079123	Placard Holder	1	EA
B47	079527	Screw;Hex Socket;BH;M8x1.25Px18L;Black Z	2	EA
B50	005181-A	Washer;;;;;?5.3x?10x0.6t;;;;;	8	PCS
B51	005180-A	OUTSIDE SAWTOOTH WASHER(SUS304)	12	PCS
B55	008523-B	Washer;Arc;SS41;	4	EA
B56	009306-E	Axle;Belt Fall-Proof;;SS41;?10x43L;Cr Pl	2	PCS
B57	004714-AD	Screw;Umbrella Hex Scocket;M6X1.0PX15L;Ad	4	PCS
C05	004885-00	HEX NUT	12	PCS
C13	041364-A	CONTube;Pulley;;;;;ø60x3.0tx94L;;GM24;GM2	2	PCS
C14	031232-A	Fix Plate;Pulley;; SPC;;;;;GM24;GM24-C12A	4	PCS
C15	031479-A	CON Plate;Pulley;;SPC;;;;;GM24;GM24-C13A	4	PCS
C21	031459-A	Fix Plate;Leg Pad ;;SPC;;;;;GM24;GM24-C08	4	PCS
C22	031478-A	CON Plate;Leg Pad ;;SPC;;;;;GM24;GM24-C09	4	PCS
C22	000585-F	Foam;?38.1x3.0tx253L;GM07	4	EA
C24	004079-00	BEARING 6006ZZ	2	EA
C27	041878-C	Fix Tube;Foot;;;;;?40.0x80.0x2.0tx225L;;;G	2	PCS
C30	000508-D	Foot Pad;?60;GM01	2	PCS
C33	004780-AC	Screw;Hex Socket;BH;M10x1.5Px25L;Adhere;	36	EA
C50	004703-AF	Screw;Hex Socket;Flat;M8x1.25Px20L;Adher	4	EA
C51	000521-A	Foot pad;;;;;Rubber;120;;GM07	4	PCS

G3S55 Rotary Torso Parts List.xls

Ref #	SAP #'s	Description	Q'ty	Unit of Measure
C53	030210-A	Sticker;Silicon Bottle;;;50cc;;;	2	PCS
C70	001443-B	End-Cap;Bolt Pin;Rubber;GM01	8	PCS
D20	069663	Ball Bearing	2	EA
D21	005354-00	Clamp;Inner C Type;R-42;	1	PCS
D22	013422-ZG2	Adjust Pin Assembly for ROM	1	EA
D23	019153-A	Pull Pin Handle, TPR	1	EA
D25	025624-AA	Flat Washer	1	EA
F09	031788-A	Pulley Alex;GM24-F09A	2	PCS
F20	035711-A	Belt;Flat;15/16";Bulk, Kevlar;Mectrol	20	EA
F20	066972-A	Belt;Flat;;;2850MM;;;GM20	2	EA
F21	022223-A	CAM COVER;SUS304(electroplate);GM24-F07A	1	EA
F22	004482-AB	ROUND HEX SOCKET SCREW	4	PCS
F23	001523-E	ROLLER STOP RUBBER	2	EA
F24	008448-D	Fix Plate;Pulley;;SPC;;BED;;GM01	2	EA
F25	025418-AA	ADJUSTABLE SWIVEL AXLE WASHER	2	SET
F26	004079-00	BEARING 6006ZZ	2	EA
F27	069820	Swivel Axle;GM24	1	EA
F31	004537-AD	Screw;Hex Socket;Round;M5x0.8Px30L;Adher	8	EA
F32	005084-00	WASHER FT M5.3X10X1 CHM	8	PCS
F33	005016-00	WASHER LK M5.1X9.3X1.3 CHM	8	PCS
F34	004519-AE	Screw;Hex Socket;Round;M10x1.5Px80L;Adhe	4	EA
F35	020098-AE	Screw;Hex Socket;Round;M10x1.5Px70L ;Adh	2	EA
F36	004943-00	Nut;Nylon;M10x1.5P;Cr;	4	EA
F37	020465-AB	FLAT WASHER	18	PCS
F39	004575-AD	Screw;Hex Socket;Sink;M8x1.25Px10L;Adher	2	EA
F40	019150-C	PULLEY;NO Drawing	8	PCS
F41	005017-00	SPRING WASHER	10	PCS
F43	009227-E	Fix Cap;Pulley;NO DRAWING	16	PCS
F44	033409-AA	Extrawork;Pulley set;;;FW63;	8	SET
J01	079560	Seat Pad;Black;GM01	1	EA
J01	086936	Seat Pad;American Beauty Red;GM01	1	EA
J01	088071	Seat Pad;Clay Red;GM01	1	EA
J01	088072	Seat Pad;Slate Blue;GM01	1	EA
J02	079561	Head Pad;Black;GM02	1	EA
J02	086937	Head Pad;American Beauty Red;GM02	1	EA
J02	088085	Head Pad;Clay Red;GM02	1	EA
J02	088086	Head Pad;Slate Blue;GM02	1	EA
J03	079525	Arm Pad;Black;GM07	2	EA
J03	086664	Arm Pad;American Beauty Red;GM07	2	EA
J03	088087	Arm Pad;Clay Red;GM07	2	EA
J03	088088	Arm Pad;Slate Blue;GM07	2	EA
J04	087594	Leg Pad;L;Black	1	EA
J04	087269	Leg Pad;L;American Beauty Red	1	EA
J04	088188	Leg Pad;L;Clay Red	1	EA
J04	088189	Leg Pad;L;Slate Blue	1	EA
J05	087595	Leg Pad;R;Black	1	EA
J05	087272	Leg Pad;R;American Beauty Red	1	EA
J05	088194	Leg Pad;R;Clay Red	1	EA
J05	088195	Leg Pad;R;Slate Blue	1	EA
J24	062626-AA	Cap;ABS;FW158	4	PCS

G3S55 Rotary Torso Parts List.xls

Ref #	SAP #'s	Description	Q'ty	Unit of Measure
K03	009641-F	Bayonet;Weight Plate;;SS41;20Aperture;;	1	EA
K04	009228-B	BELT CONNECTING RING;SS41;GM01-K04B;	2	PCS
K05	009219-D	CON Axle;Belt;;SS41;;Zn Plate(BL);;;GM01	2	PCS
K06	015942-AA	Extrawork;Weight Plate Set;;Dry Bearing;	19	EA
K07	001513-A	Elastomer Rubber Block;GM01	4	PCS
K09	022390-B	GUIDE RAIL	4	PSC
K10	014794-B	ADJ Bolt;Weight Plate;;SCM-21;;Zn Plate	1	EA
K11	001510-B	GROMMET GUIDE ROD	4	PCS
K13	005377-00	Clamp;E-Shaped;E-15;	4	EA
K14	004116-00	Dry Bearing (Bushing), GSM-2023-25	38	EA
K15	005367-00	Clamp;Outer C Type;S-30;COS300;	4	PCS
K16	009365-00	PIN SPRING	1	EA
K17	004720-AE	SCREW HEX M8X20	1	EA
K18	005040-AB	FLAT WASHER	2	PCS
K20	001508-E	LONG GUIDE RUBBER PLATE;POM;GM01-K24E	4	PCS
K25	005847-A	LANYARD PIN WEIGHT	2	PCS
L07	015805-AA	Painting;Increment Weight Plate;;BL;;	3	EA
L08	001521-E	Incremental Rubber Stopper Block	4	PCS
L09	004720-AE	SCREW HEX M8X20	2	EA
L10	005040-AB	FLAT WASHER	4	PCS
L11	005015-00	SPRING WASHER	4	PCS
L13	005016-00	WASHER LK M5.1X9.3X1.3 CHM	8	PCS
L14	004708-AD	Screw;Hex Socket;BH;M5x0.8Px16L;Adhere;	8	EA
L16	022397-A	STOP RING	4	PCS
not shown	069539	Assembly Manual ;GM24	1	EA
not shown	069543	Hardware Kit;GM24	1	EA
Q01	069508	Cover;B;GM11	2	EA
Q02	018860-BA	UPPER COVER;ABS;GM01-Q12B	1	EA
Q03	001512-C	Cover;Pulley;ABS;GM01	8	PCS
Q04	001401-A	End-Cap;?76.2;ABS;GM03	4	PCS
Q05	001402-A	COVER END	4	PCS
Q06	001405-A	End-Cover;?60;ABS;GM03	4	PCS
Q07	001526-D	Bolt;Cover;GM01-Q07D;M8x1.25Px40L	6	EA
Q10	001509-D	Fix Rubber Block;Cover;Rubber;GM01	6	PCS
Q12	020699-A	Nail;1/8"x12.5L	6	EA
V01	088343	Operation Instruction Sticker	1	PCS
V02	021588-A	ANGLE ADJUSTABLE DECAL	2	PCS
V03	006620-D	Sticker;10Pound Weight Plate;;;;;;GM13	2	SET
V04	005984-G	Cover DECAL;GM01-V08G	1	EA
V11	069536	Sticker;Serial No.;GM24	2	EA
V14	006650-B	Sticker;2.5Pound Weight Plate;;;;;;GM06	12	PCS
V17	029963-A	Sticker;Warning;;;;;;FW50;FW50-V02A	4	PCS
Z10	004555-A	SCREW ROUND-HEX-SOCK	12	PCS
Z15	020465-AB	FLAT WASHER	24	PCS
Z16	005017-00	SPRING WASHER	24	PCS
Z17	020104-AD	Screw;Hex Socket;Round;M10x1.5Px30L;Adhe	8	EA