



The BIKE:3670, 3770 / The SEMI: 3610, 3710

WHITE BIKE	3670	WHITE SEMI	3610
BLACK BIKE	3770	BLACK SEMI	3710

Part #	Description	Notes
367PR187	Bellows	
367PE186	OBSOLETE / Bellows Attachment	
3670S601	Belt, Friction - Bike before 1995, 50"	bike-< 3670H508XXX
3610S601	Belt, Friction - Bike/Semi, 52"	bike-3670H508XXX> / All Semi
367PP197	Bracket, Mounting (Molded)	
3610S377	Cable, main wire harness	Connects to all electronics/boards
3670A400	Calibration Kit, The Bike	
3610K400	Calibration Kit, The Semi	
367WC188	Caster, Concentric	Non-Adjustable
367WC189	Caster, Eccentric	Adj. W/Set Screw, Right side
361GS261	Chain, Semi	
367GS260	Chain, Upright Bike, 98 link	
3670S246	Control Rod Assy	
FC100367	Coupling	
3670K360	Crank Assy, Bike/Semi	
FB030018	Crank Bearing, New Roller Type	3670H326XXX>(round holder)
FB030016	Crank Bearing Race, 1.9697 OD	For bearing FB030018
N/A	Crank Bearing, Old Sealed Type	3670H326XXX<(square holder)
367EW345	Daisy Chain Cable	Bike to Bike
3670K100	Daisy Chain Support Bracket	
3670S699-1	Display Console, Black	REPAIR ONLY
3670S699	Display Console, White	REPAIR ONLY
3670S699-E/M	Display Console, White E/M	REPAIR ONLY
EG450000	Display Module, Vacuum Fluorescent	Lower Display - 12VDC
367PE194	OBSOLETE / Enclosure Assy, Right (White)	The Bike - Upright
367PE195	OBSOLETE / Enclosure Assy, Left (White)	The Bike - Upright
367PE194-1	OBSOLETE / Enclosure Assy, Right (Black)	The Bike - Upright
367PE195-1	OBSOLETE / Enclosure Assy, Left (Black)	The Bike - Upright
361PE181	OBSOLETE / Enclosure, Right Front (White)	The Semi
361PE181-1	OBSOLETE / Enclosure, Right Front (Black)	The Semi
361PE182	OBSOLETE / Enclosure, Left Front (White)	The Semi
361PE182-1	OBSOLETE / Enclosure, Left Front (Black)	The Semi
361PE183	OBSOLETE / Enclosure, Right Rear (White)	The Semi
361PE183-1	OBSOLETE / Enclosure, Right Rear (Black)	The Semi
361PE184	OBSOLETE / Enclosure, Left Rear (White)	The Semi
361PE184-1	OBSOLETE / Enclosure, Left Rear (Black)	The Semi
3670K030	Encoder Kit W/Pulley	
3670K701	Flywheel Bearing Kit	
EF290010	Fuse, 1 Amp, 250V	For Power Entry Module(PEM)
3670S310	Hall Effect BD	
367PP129	Handle Bar Grip, Bike	
361PP149	Handle Bar Grip, Semi	

3670K020-1	Handle Bars W/Grips, Black	
3670K020	Handle Bars W/Grips, White	
3670S800	Heart Rate Circuit Board	
AD-13930	Heart Rate Transmitter Belt	Polar Belt
AD-14177	Heart Rate Transmitter Belt with Watch	Polar Belt & Watch
3670K351	Keypad Kit, Black, Overlay & Front Cover	Only BLEMISHED available
3670K350	Keypad Kit, White, Overlay & Front Cover	Only BLEMISHED available
367CM295	Label, "The Bike", White	
367CM295-1	Label, "The Bike". Black	
361CM276-1	Label, "The Semi". Black	
367cm299	Label, Logo, Cybex	Decal on console post
YA000038	Loctite #290	
3670D6000	Manual, The Bike Service/Parts	
3670D0003	Manual, The Bike/Semi Owners	
3610D6000	Manual, The Semi Service/Parts	
367EM250	Motor, Bike/Semi	DC Tension Motor
HN704400	Nut, Jam, 3/8-16	
AX-50068	Pedal Set, 1/2"shaft, with Straps	1
367GT285	Pedal Strap, Left	
367GT284	Pedal Strap, Right	
3670M545	Pivot Rod	
WR-11789	Power Cord	
ES000367	Power Entry Module (P.E.M.)	Requires 1 Amp Fuse
EP470367	Power Supply	120VAC in - 12 & 5VDC out
3610M129	Roller, Carriage	
HM621814	Screw, Pan-L, 1/4-20 x 5/8 (White)	Console
HM621815-3	Screw, Pan-L, 1/4-20 x 3/4 (Black)	Console
HC701216	Screw, 3/8-16 x 7/8", hex hd cap	
HC662815	Screw, 5/16-18 x 3/4", sckt hd cap	
HY702917	Screw, Set, 3/8-16 x 1"	
Z-02	Seat release lever, BLACK	n stockroom as Z-02, (3610C156)
3670M135	Seat, Molded, Upright	
3670K137	Seat Post Kit, Upright w/label	Does not include seat pad
3610M135	Shaft, Roller (Vertical Ecc.)	
3610M136	Shaft, Roller (Vertical)	
BR030043	Snap Ring, external, 3/4 OD	
BS070367	Spring, Tension Belt	
BS071367	Spring, Compression, Threaded Rod	
BS072367	Spring, Torsion, Chain Tensioner	
3670K400	Threaded Rod Kit	
GB000367	Timing belt	
FB030100	Washer, Thrust, .75ID x 1.25OD	