


Example of a starting Serial # RT4060210000001

| | | | |
|---------|---------|------------|---------------|
| RT4 | 06 | 0210 | 000001 |
| Model # | Plant # | Year/month | Serial Number |



CONSOLE ASSEMBLY (ENG/ENG)
REX22D8

