


LifeFitness

ARCTIC SILVER CROSS TRAINER 95X-0XXX-02



Customer Support Services **PARTS MANUAL** rev. 11/10/05

OPERATION MANUAL	M051-00K62-A072
SERVICE MANUAL	M051-00K62-A060
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
CRANKSHAFT W/BEARINGS KIT	GK62-00002-0028
HARDWARE BAG	AK62-00152-0001

	Page
CONSOLE SUPPORT & DEADSHAFT COVERS	4
HANDLEBARS AND BULLHORNS	5
CONSOLE AND RELATED COMPONENTS	6
UPPER FRAME HARDWARE	7
ROCKER ARMS AND PEDAL LEVERS	8
CRANK COVER AND LOWER CAPS	9
LOWER FRAME SHROUDS AND HARDWARE.....	10
PEDAL LEVER COMPONENTS	11
DRIVE MODULE COMPONENTS AND MAIN CABLE	12
DRIVE MODULE HARDWARE	13
CABLES	14

Note: The 95Xi comes with both Telemetry and LifePulse Sensors.

ARCTIC SILVER 95Xi
Console Support & Deadshaft Covers


95X-0XXX-02
S/N ACJ100000 and up

Console Support
AK62-00123-0000
Console Support Cap
0K62-01030-0000
Console Support
Shroud
0K62-01023-0000

Right
Bullhorn Cover
0K62-01007-0001
Left
Bullhorn Cover
0K62-01008-0001

Right Inside
Deadshaft Cover
0K62-01010-0000
Left Inside
Deadshaft Cover
0K62-01011-0000
2-Front Inside
Deadshaft Cover
0K62-01009-0000

2-Outside Front
Deadshaft Cover
0K62-01013-0000
2-Outside Rear
Deadshaft Cover
0K62-01012-0000



ARCTIC SILVER 95Xi
Handlebars and Bullhorns

95X-0XXX-02
S/N ACJ100000 and up


Right Handlebar
AK62-00086-0000

*Right Bullhorn
AK62-00053-0001
Left Bullhorn
AK62-00054-0001

HR Sensor Kit
GK20-00002-0005

Medallion Bug
AK58-00245-0000
Bug Adaptor
0K62-01034-0000


Left Handlebar
AK62-00087-0000
Heart Rate Cable
AK61-00051-0001
(one per handlebar)



*Right Bullhorn Assembly consists of: AK62-00057-0001 Bullhorn,
0K62-01136-0000 Grip and 0K62-01199-0000 Gasket
Left Bullhorn Assembly consists of: AK62-00058-0001 Bullhorn,
0K62-01136-0000 Grip and 0K62-01199-0000 Gasket

ARCTIC SILVER 95Xi
Console & Related components


95X-0XXX-02
S/N ACJ100000 and up



CONSOLE	OVERLAY/BEZEL/SWITCH	LANGUAGE
AK62-00149-0001	AK62-00191-0001	Eng + Met
AK62-00149-0003	AK62-00191-0003	Ger/Met
AK62-00149-0004	AK62-00191-0004	Spn/Met
AK62-00149-0006	AK62-00191-0006	Jap/Met
AK62-00149-0007	AK62-00191-0007	Frn/Met
AK62-00149-0008	AK62-00191-0008	Ital/Met
AK62-00149-0009	AK62-00191-0009	Dut/Met
AK62-00149-0010	AK62-00191-0010	Port/Met

ARCTIC SILVER 95Xi
Upper Frame Hardware

95X-0XXX-02
S/N ACJ100000 and up




Items Not Shown:

Accessory Tray	0K62-01022-0000
Mounting Screws (2)	0017-00101-1846


ARCTIC SILVER 95Xi
Rocker Arms & Pedal Levers

95X-0XXX-02
S/N ACJ100000 and up



ARCTIC SILVER 95Xi
Crank Cover and Lower Caps

95X-0XXX-02
S/N ACJ100000 and up




Crank Cover
0K61-03100-0002
2 - Mounting screws
0017-00101-1837

Stabilizer Caps
4 - 0K62-01003-0000

Front frame Cap
0K62-01004-0000
Mounting Screws
(Located on front sides of Ladder Frame Cover)
2- 0017-00101-1795


ARCTIC SILVER 95Xi
Lower Frame Shrouds & Hardware

95X-0XXX-02
S/N ACJ100000 and up



ARCTIC SILVER 95Xi
Pedal Lever Assembly Components

95X-0XXX-02
S/N ACJ100000 and up



ARCTIC SILVER 95Xi
Drive Module components

95X-0XXX-02
S/N ACJ100000 and up

