







REF#	PART#	DESCRIPTION
1	93900	FRAME
2	93905	COMPUTER MAST
3	93913	SEAT TUBE
4	93911	HANDRAIL W/ HAND GRIP CABLE
5	95160	REAR STABILIZER
6	98306	SEAT BACK PAD
7	98307	SEAT BOTTOM PAD
8	98513	COMPUTER
9	98156	PEDALS
10	93910	SEAT RAIL ENDCAP
11	93906	COMPUTER WIRE 850L 8 PIN
12	93907	UPPER HAND GRIP CABLE 1000L 4 PIN
13	93902	HAND GRIP CABLE 1200L 4 PIN
14	93901	CABLE BRACKET 8 X 14.5 PLASTIC
15	93904	SPRING 0.6 X 9 X 150L
16	95882	ROUND HEAD SCREW M5 X 0.8 X 15L
17	93148	WASHER 5.5 X 13 X 1.0T
18	93903	CONTROLLER WIRE 850L 8 PIN
19	98137	PEDAL STRAP SET
20	95456	NYLON NUT M6 X 1.0
21	98437	WASHER 6.5 X 13 X 1T
22	95668	SEAT STOP
23	98438	SELF TAPPING SCREW M5 X 15L
24	98439	SCREW M6 X 1.0 X 110L
25	98440	ALLEN BOLT M8 X 1.25 X 16L
26	93114	ALLEN BOLT M8 X 1.25 X 40L
27	93253	HEX BOLT M8 X 1.25 X 20L
28	95623	SPRING WASHER SW8
29	98522	WASHER 8.4 X 17 X 2.0T
30	95169	COMPUTER BRACKET END CAP
31	95669	GRIPS, HANDLEBAR
32	95190	HANDLEBAR PLUG
33	93229	ROUND HEAD SCREW M5 X 0.8 X 12L
34	95145	BOTTLE CAGE
35	93908	HANDLEBAR SHROUD CAP 60 X 60 X 18.5H
36	93122	GRIPS, HANDRAIL
37	93912	HAND GRIP CABLE 600L 4 PIN
38	98441	WASHER 6.2 X 19 X 2T
39	98442	HEX BOLT M6 X 1.0 X 16L
40	95675	SEAT RAIL FRONT COVER
41	93918	POLY-V BELT 8V X 813L
42	98533	INTERMEDIATE PULLEY 175 X 22W
43	95196	WASHER 15 X 29 X 2t
44	95197	INTERMEDIATE BEARING NK 15/16
45	95477	WASHER 16 X 22.8 X 3t
46	95191	C RING 15MM I.D.
47	98538	SMALL PULLEY M8 X 28T
48	93919	PULLEY LOCKNUT M8 X 1.25
49	93920	PULLEY LOCKWASHER t=1.5
50	91731	NYLON NUT M8 X 1.25
51	98523	CONTROLLER
52	93922	ROUND HEAD SCREW M4 X 0.7 X 15L
53	93584	HEX NUT M4 X 0.7
54	93587	WASHER 4.2 X 10 X 1T
55	98444	SPRING WASHER SW5
56	92433	SCREW M5 X 0.8 X 10L
57	98527	HEX BOLT M10 X 1.5 X 35L
58	93921	IDLER ARM
59	95933	IDLER PULLEY 56 X 50 X 22L
60	93559	DU BEARING 14 X 16 X 11L
61	93817	KEY 5 X 5 X 8L
62	98530	ALLEN BOLT M5 X 0.8 X 15L
63	98526	SPRING 1.6 X 12 X 67
64	93556	C-RING 8
65	93558	C-RING 14
66	98445	HEX NUT M6 X 1.0
67	98546	SENSOR BRACKET 30 X 18 X 20L
68	93923	SENSOR W/CABLE 580L
69	98446	SCREW M3 X 0.5 X 8L
70	95189	BOTTOM BRACKET SET
71	95192	CRANK BEARING 6005 RS
72	95474	SENSOR MAGNET
73	93916	CRANK PULLEY 8M X 80T
74	93917	SCREW M6 X 1.0 X 15L
75	98542	DRIVE BELT 8MA-1040-15W
77	98520	CRANK W/ PULLEY BRACKET
78	95681	SEAT LOCKING BLOCK
79	93909	SEAT RAIL



REF#	PART#	DESCRIPTION
80	93914	BRAKE
81	93924	LEFT SHROUD
82	95609	SHROUD PLUG 23 X 18.7 X 13.5L
83	95604	ROUND HEAD SCREW M5 X 0.8 X 20L
84	93925	RIGHT SHROUD
85	95576	STABILIZER END CAP
86	95577	LEVELER NUT
87	90595	LEVELER FOOT
88	95880	HEX BOLT M8 X 1.25 X 90L
89	98525	ALLEN BOLT M6 X 1.0 X 16L
90	93562	SPRING WASHER SW6
91	97970	BEARING 608ZZ
92	98448	GUIDE ROLLER BRACKET
93	95182	TRANSPORT WHEEL SLEEVE
94	95187	TRANSPORT WHEEL
95	95199	WASHER 8.5 X 26 X 2.5T
96	95606	SCREW M4 X 12L
97	95198	HEX BOLT M8 X 1.25 X 16L
98	98443	WASHER 8.5 X 19 X 1t
99	93926	SEAT TUBE PLUG
100	95682	SEAT LOCKING LEVER
101	95683	SEAT GUIDE ROLLER
102	95684	SEAT WHEEL
103	95685	SEAT WHEEL CAM AXLE
104	93927	WASHER 10.4 X 26 X 2.0t
105	93928	WASHER 10.7 X 16 X 2.0t
106	93929	NYLON NUT M10 X 1.5
107	93930	FLANGE NUT M8 X 1.25
108	93931	HEX BOLT M6 X 1.0 X 70L
109	93932	HEX BOLT M6 X 1.0 X 80L
110	93933	HEX BOLT M8 X 1.25 X 150L
111	95686	SPRING SLEEVE 6.2 X 14.5 X 13
112	95687	GUIDE ROLLER SLEEVE 8.2 X 12.7 X 101L
113	95688	GUIDE ROLLER SPACER 8.2 X 12.7 X 10L
114	95689	SPRING 20 X 15 X 12.5L
115	93934	C-RING 10
116	97958	SEAT ADJUSTING BRACKET
117	93935	HEX BOLT M8 X 1.25 X 12L
118	93936	SCREW MOUNT ZIP TIE
119	98550	HEARTRATE GRIP ASSEMBLY 8 PCS.
120	90130	HEARTRATE RECIEVER SET
	92953	QUALITY SEAL
	93937	HARDWARE PACK
	93938	DECAL SET
	93939	OWNER'S MANUAL
	91547	920 ELITE SELL SHEET