



Date	Revision	Date	Revision
08.18.00	11=11A, 74=74A	01.17.00	Added 81; Cancelled 16, 42, 66
05.25.01	Added 81	04.11.00	9=9A; Added 82
06.21.01	31=31A; Added 85	05.23.00	Added 83; Cancelled 32, 33, 34

Model: 3120 / 3150
Pic: BP-F001A

SportsArt FITNESS

3120 / 3150

11/22/2002

Bbl#	Description	Qty	Part #
1A	Display w/ HTR - 3120	1	3120-01A
*	Display, 3120 - Recond.	1	3120-01R
1D	Display w/ HTR+HRC - 3150	1	3150-01D
*	Display, 3150 - Recond.	1	3150-01R
2B	HR receiver (for use w/ HTR)	1	3200-83
3	Heart-rate strap	1	3100-03
6	Handlebar plug	2	1200-64
8C	Handlebar - Long w/ HTR - L	1	3120-08
8D	Handlebar - Long w/ HTR - R	1	3120-08A
9A	Safety key	1	1200-02
11A	N/A - Refer to #74A	0	N/A
12	Water bottle holder	1	1200-06
13	Handlebar bracket - Bottom	2	1200-09
14	Shoulder bolt	2	BT01-01
17	Nylon sleeve	2	1200-11
18	Rear end cap - Top right	1	1200-12
18A	Rear end cap - Top left	1	1200-12A
19	Rear end-cap	2	1200-13
20	Walking belt	1	3100-20
22	Rear roller	1	1200-62
23	Leveler	2	1200-15
24	Rear support w/ leveler	2	1200-14
26	Landing strip (deck trim)	2	3100-26
27	Pin	1	3100-27
28	Nylon gear (Also see #84)	1	3100-28
29	VR (potentiometer) assembly	1	3100-29
30	Elevation motor	1	3100-30
*	Cover, Elev. motor (31XX)	1	3100-30A
31A	Frame	1	3100-31
35	Front roller	1	1200-53
36	Front end-cap	2	1200-32
37	Pin	1	3100-27
38	Fuse - 15A, main	1	F15F-01
39	Fuse holder	2	FSHR-01
40	Fuse - 4A, elevation	1	F4AT-01
41	ON/OFF switch	1	ONSW-01
43	Deck	1	3100-43
44	Deck bushing	4	1200-54
47	Insulator	1	3100-47
48	Transformer	1	3200-18
49	Motor adjuster	1	1200-39
50	Drive belt - #210J	1	3100-50
51	Drive motor	1	3100-51
*	Motor brushes	2	3100-51A
52A	Optical switch	1	3007-28
*	Optical switch & wheel - Kit	1	3007-28K
53	Sensor wire	1	3100-53
54A	Fuse - 10A	1	F10F-01
55A	Resistor	1	3100-55
56A	Optical wheel	1	3007-29

Bbl#	Description	Qty	Part #
57	Power cord	1	1200-47
58	Drive board	1	3100-58
*	Drive board - Recond.	1	3100-58R
*	Fuse - 3A, drv brd, 5x20 mm	1	F3ST-01
59	Pin	2	3100-59
60	Transport wheel	2	3100-60
61	Elevation frame	1	3100-61
62	Bushing	2	3100-62
63	Hood	1	3100-63
64	Stand off	2	1200-71
65	Wire holder	1	1200-72
67	Fuse holder for resistor	1	3100-67
68	Cable holder - Bottom	1	1200-73
69	Wire - HTR board to handlebar	1	3100-73
70	HTR PC board	1	3100-74
71	Fastener	2	3100-70
72	Bracket - Optical switch	1	3100-72
73	Handlebar bracket - Top	2	1200-04
74A	Pedestal	1	3100-71A
75	Handlebar, Short w/ HTR - R	1	3100-06D
76	Handlebar, Short w/ HTR - L	1	3100-06E
77	Nut clip	4	1250-111
78	Cushion - Full length	2	3100-46
79	Wire - HTR board to display	1	3200-82
81	Ribbon cable	1	1200-90
82	Cable holder - Top	1	1200-80
83	Belt guide roller	2	1200-56
84	Nylon gear B	1	3100-28A
85	Steel cover	1	3100-82

PARTS NOT SHOWN OR DISC

*	Label - Frame, oval - L&R set	1	1200-84
*	Belt positioning decal	2	1200-91
*	PCB wire set	1	1200-93
*	Hardware package	1	3100-85
*	Label - Frame rail 3120 (disc.)	2	3120-90
*	Label - Frame rail 3150 (disc.)	2	3120-91
*	Label - "3120"	2	3120-92
*	Label - "3150"	2	3120-93
*	3120 Owners manual	1	3120-OM
*	3150 Owners manual	1	3150-OM
*	Keypad & overlay - 3120	1	3120-95
*	Keypad & overlay - 3150	1	3150-85