



Date Revision
 09.06.04 Added 16B, 19B, 74B, 79B, 102
 06.29.04 Changed 16=16A, 19=19A, 74=74A, 79=79A
 02.06.04 Changed 90=90A; Added 101

Model: E82
 Version: 4; Diagram: DT-F001A
 Date: 12.01.04

SportsArt FITNESS

E82

01/05/05

Bbl#	Description	Qty	Part #
1	DISPLAY - E82	1	E82-01
2	DISPLAY BACK PIECE	1	51U-02
3	CUP HOLDER	1	51R-03
4	HANDLEBAR (NO HTR)	1	E82-04
5	GRIP CAP	2	1200-64
6	WIRE - STRIDE SWICTH	1	805P-07
7	GUIDE - WHEEL STRIDE	12	8300-99
8	STRIDE LENGTH CONTROLER	1	8300-13
9	STRIDE CONTROL MOTOR - R	1	8300-17
10	INSIDE JOINT COVER - R	1	8300-14
11	OUTSIDE JOINT COVER - R	1	8300-15
12	FRAME SUPPORT - R	1	8300-30
13	SUPPORT BAR COVER	2	8300-98
14	FRAME SUPPORT - L	1	8300-67
15	ACCESS COVER	2	8300-18
16	STRIDE SUPPORT ARM - L	1	E82-16
17	GUIDE ROLLER	2	805P-16
18	AXLE FOR GUIDE ROLLER	2	E82-18
19	STRIDE SUPPORT ASSY	1	E82-19
20	PEDESTAL	1	E82-20
21	ROLLER COVER	2	8300-27
22	PROTECTIVE PIECE	2	E82-22
23	END CAP	2	E82-23
24	INNER PANEL	1	E82-24
25	STOPPER	2	1200-15
26	BOLT	2	E82-26
27	CARRIAGE ASSY - L	1	E82-27
28	GUIDE ROLLER	2	805P-16
29	BUSHING - LOWER GUIDE	2	805P-82
30	BOLT - LOWER GUIDE	2	805P-81
31	BOLT	2	805P-21
32	STRIDE LINKAGE - R	1	805P-41
	STRIDE LINKAGE - R, SILVER	1	805P-41B
33	STRIDE RAIL	2	805P-25
34	INNER PANEL - L	1	E82-34
35	END CAPS ROUND	2	5007-20
36	LEVELER FRONT	2	8300-44
37	FRAME	1	E82-37
38	WIRE - VR ASSY - R	1	805P-07
39	COVER	2	805P-39
40	BOLT & BUSHING	2	805P-40
41	DATA CABLE	1	805P-24
42	WIRE - VR ASSY - L	1	805P-32
43	MOUNTING PLATE	1	805P-52
44	BUSHING - LOWER GUIDE	2	805P-42
45	TRANSFORMER	1	805P-51
46	LINKAGE KNUCKLE	2	805P-43
47	CRANK ARM	2	805P-44
48	WEDGE PIN	2	8100-66
49	WIRE HARNESS - ON SWICTH	1	805P-46
50	IDLER PULLEY - TOP	1	805P-47
51	SPRING	2	2100-28
52	IDLER PULLEY - BOTTOM	1	805P-49
53	POWER INLET ASSY	1	E82-53
54	WIRE HARNESS - REAR	1	805P-50
55	END CAP ROUND	2	E82-55
56	WHEEL AXEL	2	3100-59
57	TRANSPORT WHEEL	2	805P-57
58	FUSE 1A	1	F1AT-01
59	FUSE HOLDER	1	FSHR-01
60	ON OFF SWICTH	1	ONSW-01

Bbl#	Description	Qty	Part #
61	BRACKET	1	803-65
62	POWER CORD	1	E82-62
63	LEVELER - REAR	2	7100-34
64	DRIVE BOARD	1	E82-64
65	OPTICAL SWICTH	1	805P-61
66	SPINDLE	1	805P-65
67	DRIVE PULLEY	1	805P-64
68	INSULATOR	1	805P-66
69	WIRE - DISPLAY TO DRIVE B.	1	805P-69
70	COVER	1	E82-70
71	BELT 490J7	1	5005-28A
72	SUPPORT COVER BOTTOM	1	E82-72
73	SUPPORT COVER TOP	1	E82-73
74	STRIDE SUPPORT - L	1	E82-74
75	PLUG	2	E82-75
76	INNER JOINT COVER - L	1	8300-33
77	OUTSIDE JOINT COVER - L	1	8300-34
78	WIRE - LEVEL SWICTH	1	805P-32
79	STRIDE SUPPORT ASSY - L	1	E82-79
80	RESISTANCE LEVEL CONTROL	1	8300-36
81	STRIDE CONTROL MOTOR - L	1	8300-37
82	PLUG	1	E82-75
83	SIDE COVER - R	1	E82-83
84	FLYWHEEL	1	805P-67
85	NUT PLATE	1	805P-70
86	STRIDE LINKAGE - L	1	805P-72
	STRIDE LINKAGE - L, SILVER	1	805P-72A
87	PEDAL CARRIAGE	1	E82-87
88	FOOT PEDAL	2	8100-54
89	SIDE COVER - L	1	E82-89
90	HANDLEBAR W/HTR	1	E82-90
91	POLAR HR RECEIVER	1	8300-84
92	POLAR STRAPS	1	3100-03
93	WIRE - HTR PCB TO HANDLEB	1	8300-81
94	HTR BOARD	1	3100-74
95	R/B # 01		
96	R/B # 01		
97	R/B # 01		
98	WIRE - HTR PCB TO DISPLAY	1	8300-80
99	R/B # 91		
100	SLEEVE	2	8300-32

ADDITANAL PRTS NOT SHOWN

*	HARDWARE PACKAGE	1	E82-110
*	OVERLAY	1	E82-111
*	OWNERS MANUAL	1	E82-OM
*	CRANK BEARINGS - 62042	2	8003-73
*	Stride Link. Bearing Front 6002ZZ	4	805P-101
*	Stride Link. Bearing Rear 6001ZZ	4	5006-55

0091658 SILVER UNITS STARTED