

REFERENCE - PARTS PRICE LIST

BIKES - STEPPERS - ELLIPTICALS

Part Number	Load Control Boards
721-0022	ACB Elliptical
720-5023	ACB ProBikes
800-3150	ACB UB\RB\SS

Part Number	Load Control Boards - Refurbished
800-3350	ACB Refurb Elliptical
	ACB Refurb ProBike
800-3251	ACB Refurb UB\RB\SS

Part Number	Alternators
721-0019	Alternator Elliptical
718-5024	Alternator ProBikes
800-3122	Alternator UB\RB\SS

Part Number	AC Adapters
800-3326	1 of 2 AC-DC Power Supply 9v 50w EE/ProBikes
800-3357	2 of 2 AC-DC Line Cord for Adapter EE/ProBikes
800-3145	AC Adapter 9-13VDC 800mA SS/UB/RB
	AC Adapter 9-13VDC 800mA (Radio Shack Cat # 273-1631)

Part Number	Batteries
580-0305	Battery 6.0v 2.5a Elliptical and ProBikes
800-3102	Battery 6.0v UB\RB\SS

Part Number	Cables
721-0011	Display Cable Elliptical
721-0010	Power Cable Elliptical
721-0011-001	Display Cable ProBikes
721-0010-001	Power Cable ProBikes
718-0001	Display Cable UB\RB
800-3117	Display Cable (upper section) SS
800-3106	Display Cable (lower section) SS

Part Number	Crank & Bracket Assemblies
721-0002	Crank Assy Elliptical

718-0220	Crank Assy Bikes
800-3140	Adjustment Bracket Assy SS

Part Number	Transfer Cases / Transmissions
--------------------	---------------------------------------

721-0003	Transmission Elliptical
718-5032	Transfer Case Bikes
718-0020-002	9.5" Pulley w/ Clutch Bikes (130-1687 e-clips)
718-0020	9.5" Pulley w/ Clutch Bikes (small diameter)

Transfer Assy Cost Complete-->

Part Number	Belts
--------------------	--------------

130-1666	Drive Belt Elliptical
130-1652	Alternator Belt Elliptical
130-1648	Stride Belt old style <long> Elliptical (up to sn E0022997)
130-1682	Stride Belt new style <short> Elliptical (sn E0022998 and up)
130-3060	Powergrip Belt 4300 \ 5300
130-3070	Alternator Belt 4300 \ 5300
130-7007	Powergrip Belt 4400 \ 5400
130-7004	Alternator Belt 4400 \ 5400
800-3107	Drive Belt SS
800-3121	Alternator Belt SS

Part Number	Display Electronics
--------------------	----------------------------

715-3320-01	Display Electronics Elliptical \ ProBikes
718-0130	Display Electronics UB\RB

Part Number	Display Electronics - Refurbished
--------------------	--

800-3418	Display Electronics Refurb Elliptical \ ProBikes
800-3066	Display Electronics Refurb UB\RB

Part Number	Eproms
--------------------	---------------

621-0018-PRG	Eprom Display ver 5.79a Elliptical
621-0001-PRG	Eprom Lower ver 4.0 Elliptical
621-0009-PRG	Eprom Display ver 5.18a ProBikes
621-0008-PRG	Eprom Lower ver 0.8 ProBikes
	Eprom Display ver 5.79 PEP

Part Number	Key Pad Overlays
--------------------	-------------------------

050-1733	Keypad Overlay Elliptical \ ProBikes left
050-1734	Keypad Overlay Elliptical \ ProBikes center
050-1735	Keypad Overlay Elliptical \ ProBikes right

Part Number	Displays
-------------	----------

800-3215	Display Panel 4300 \ 4400
800-3195	Display Panel 4100 \ 3100 Led **Not LCD**

Part Number	V-Bikes
-------------	---------

800-3286	Seat
800-3289	Tension Handles
800-3420	Brass Nut
800-3302	Pedals
800-3405	Pedal Straps
800-3324	Special Pedals
800-3426	Steel Crank
800-3280	Bottom Bracket
800-3299	Handlebars
800-3359	Grip Set
800-3295	Chain
800-3290	Adjustable Foot
800-3429	Rubber Wheel
800-3331	Bottle Holder
800-3423	Warning Labels

Part Number	Heart Rate & Polar Systems
-------------	----------------------------

720-0049	Heart Rate Grip 4400	2
718-1000	Heart Rate Grip 4300	2
	HR Grip molded, top 53l	2
	HR Grip molded, bottom	2
715-3132	Combiner Board 4300\4400	
715-3347	Combiner Board ProBikes \ EE	
140-2497	Contact HeartRate Board	
140-2495	Polar Transmitter & Belt	

Part Number	Seat Posts
-------------	------------

800-3427	Long Seat Post - V-Bike
800-3439	Small Diameter Seat Post - V-Bike
800-3438	Small Diameter Handlebar Post - V-Bike
800-3317	Handlebar/Seatpost Sleeve - V-Bike
800-3436	Long Seat Post - 5300

Part Number	Misc Parts
-------------	------------

110-1790	Tinnerman Clip Nuts
240-6735	Tinnerman Clip Nuts #10 Right Angle

