



## BikeMax Recumbent

Friction Belt Drivetrain, S/N 600000-609000,

Part #	Description	Qty.
<b>ACCESSORIES</b>		
LT-03017	Manual, Owner's, old-style metal console	1
LT-03052	Manual, Owner's, new-style plastic console	1
HA-50007	Polar Transmitter/Chest Strap	1
HX-51904	Reading Rack, Plastic	0
PL-51670	Water Bottle Holder, plastic	1
<b>COVERS/HANDRAILS</b>		
PL-61275	OBSOLETE, Cover Set, Black	1
AX-61274	Cover Set, White	1
HS-41006	Screw, #10-24 x 1/2" Self-tap [Cover]	8
HS-41027	Screw, #6-32 x 1/2" Blk Phillip [Console]	4
<b>ELECTRICAL</b>		
AX-61168	Cable, CT, Base	1
AW-14132	Cable, CT, Display	1
SK-17995	Cardio Touch Board w/ Instructions	
AD-17804	Cardio Touch from X07-09	
AD-61503	CardioTouch Board REPLACED by AD-17804	1
AC-61458	Console, New-Style - Polar Only	1
AC-61459	Console, New-Style - CardioTouch	1
AC-61107	NOT AVAILABLE, Console, old-style metal,	<b>REPAIR ONLY</b>
AD-61439	Display Board for new-style console, Console changed at 607089	1
AX-61134	NOT AVAILABLE, Display Board for old-style metal console	<b>REPAIR ONLY</b>
AW-14072	Display Cable, Lower, Base-Mounted (5/96 or later)*	1
AW-14076	Display Cable, Upper, Console-Mounted (5/96 or later)*	1
	*Previous to 5/96 a single display cable was used. Replace with above cables	
AX-61124	E-Prom	1
EF-33017	Fuse, 1/4 A for Universal Power Board	1
AX-61364	NOT AVAILABLE, Motor Assy	<b>REPAIR ONLY</b>
DE-51720	Overlay for new-style console	1
DE-51971	Overlay for old-style console	1
AX-71091	Polar Receiver for either console	1
SK-16334	Power Board, Universal 110/220V	1
AW-14007	Power Cord, 10 foot	1
WR-14012	Power Cord, European Line	1
AW-14004	Power Cord, Daisy Chain, up to 8 bikes	0
AX-61267	RPM 1 Sensor (flywheel)	1
AX-61109	RPM 2 Sensor (drivewheel)	1
DE-51384	RPM Disc	1
PS-43217	Standoffs for CardioTouch board	4
AX-61303	Switchplate Assy	1
<b>MECHANICAL</b>		
FM-51505	Axle, flywheel	1
HB-44046	Bearing, flywheel	1

Part numbers and Prices subject to change without notice

AX-61223	Bottom Bracket Assembly	1
AX-71049	Crank Arm Kit, includes both crank arms and screws	1
HX-51599	Crank Arm, Left	1
HX-51600	Crank Arm, Right	1
BD-45017	Drive Belt, Poly-V	1
AX-61140	Drivewheel Assembly	1
AX-71094	Fittings Kit for Console Upgrade	0
BD-61243	Friction Belt 3/4" Belt >500909	1
AX-45022	OBSOLETE / Friction Belt 1/2" Belt <500909	1
AX-61215	Hub/Bearing Assy	1
AX-71069	NOT AVAILABLE Idler Pulley Kit	1
AX-46024	Pedal Set, One Pair - 9/16" pedal shaft	1
367GT284	Pedal Strap Right 12.24"	1
367GT285	Pedal Strap Left 12.24"	1
HS-41081	Screw, Crank	2
FM-51288	Shaft, Clutch	1
CW-05052	Transport Wheel, Front	2
PL-05053	Transport Wheel, Front - Insert(mounts in frame)	2

### SEAT SHUTTLE PARTS

SK-17365	Seat Pad, includes mounting hardware	1
AX-70126	OBSOLETE Seat Shuttle Assy, non-CT	1
AX-70351	OBSOLETE Seat Shuttle Assy, CardioTouch	1
AX-61297	Seat Rail	1
AX-71092	Kit, Seat Adjustment, 2 blocks, 4 screws	0
HX-51309	Block, Seat Adjustment	2
HX-05085	Hand Grip	2
AX-61265	Roller, Bottom	4
AX-61264	OBSOLETE Roller, Top (wide)	2
HS-41112	Screw, Seat Adjustment Block	4
FM-51507	Shaft, Bottom Roller, Eccentric	2